


Replacing the battery

Your HI battery size is 13. A worn out battery should be removed immediately and disposed of according to local regulations.

- Open the battery door completely by pushing the raised edge at the bottom of the instrument. Remove the old battery.
- Remove the sticky label from the + side of the new battery.
- Insert the new battery. Ensure that the positive (+) marking faces the positive (+) sign printed on the battery door. Close the battery door.



For instruction videos please visit:
www.youtube.com/users/OticonPeopleFirst

oticon
PEOPLE FIRST